

# Q-SHIELD Stand-alone

## Configuration Manual



### WARNING

#### **Read all safety warnings and instructions**

Failure to follow the safety warnings and instructions may result in electric shock, fire and/or serious injury.

**Save all warnings and instructions for future reference**

# Table of Contents

<b>Introduction</b> .....	<b>4</b>
About Configuration Manual.....	4
<b>Features</b> .....	<b>5</b>
DeltaQC overview .....	5
Menu list.....	5
Toolbar .....	6
Assembly Line area.....	6
Assembly Line details area .....	7
Status bar.....	7
Build area .....	7
Log area .....	7
Search function .....	7
How to copy and paste a Pset/Route.....	7
How to delete a Pset/Route .....	7
How to delete multiple Psets/Routes .....	8
Working in Online mode .....	8
Connecting a device for the first time.....	8
Connecting a device.....	8
Creating a Pset online.....	8
How to configure the controller parameters .....	9
How to transfer online data to the database .....	10
How to reset the device memory.....	11
How to display the device information.....	11
How to display diagnostic reports .....	11
Working in Offline mode .....	11
Creating a Pset offline.....	12
Route.....	12
How to create a database backup file .....	14
How to restore a database backup file.....	14
How to export one or more Psets.....	15
How to import one or more Psets.....	15
Results viewer .....	15
How to view the results .....	15
Curves viewer.....	17
How to view curves .....	17
How to compare curves .....	19
Statistics .....	20
How to create statistics .....	20
Statistics charts and reports.....	21
<b>References</b> .....	<b>24</b>
Tightening strategies .....	24
Production strategies .....	24
Quality control strategies.....	30
Pset parameters .....	37

Torque parameters.....	37
Angle parameters.....	38
Vibration parameter.....	39
Time parameters.....	40
Batch parameters.....	41
Options parameters.....	41
Correction Coefficients for extensions.....	42
How to calculate the Torque Correction Coefficient.....	42
How to calculate Angle Correction Coefficients.....	43
Correction formulas.....	43

# Introduction

## ***About Configuration Manual***


This configuration manual describes how to configure a **Q-SHIELD Stand-alone** using **DeltaQC**.

- ① For more information on how to operate a **Q-SHIELD Stand-alone**, refer to **Q-SHIELD Stand-alone** Product Instructions (printed matter 6159929570) available at <https://www.desouttertools.com/resource-centre>.

# Features

## DeltaQC overview

After launching DeltaQC, the following window is displayed:















A	Menu list	B	Toolbar
C	Assembly Line area	D	Assembly Line details area
E	Log area	F	Status bar
G	Build area		

## Menu list

Item name	Description
File	<b>Database:</b> create and restore a database backup file. <b>Exit:</b> exit from the DeltaQC software.
View	<b>Build area, Tree, Details, Log area, All:</b> select/deselect the areas to show in the workspace. <b>Restore default layout:</b> restore the default areas of the workspace.
Transfer	<b>PC --&gt; Device:</b> transfer data from the PC to the device. <b>Device --&gt; PC:</b> transfer data from the device to the PC.
Real Time	Not available.

Item name	Description
Options	<p><b>Change language:</b> set DeltaQC language.</p> <p><b>Enable log file:</b> enable/disable the log file.</p> <p><b>List available devices:</b> open the list of the available devices.</p>
Service	<p><b>Registration:</b> register the software.</p> <p><b>Change license:</b> register a new license.</p> <p>For further information on how to register the software and change license, refer to DeltaQC Installation and Upgrade manual.</p>
About	<b>About...:</b> information on the software, registration and license.

## Toolbar

Icon	Icon name	Description
	Save	Save the items defined in the Assembly area.
	Undo	Cancel operations on items in the Assembly area.
	Transfer PC --> Device	Transfer data defined offline to the device connected to the PC.
	Transfer Device --> PC	Transfer data defined online from the device to the PC.
	Controller	Open information and settings of the connected device.
	Bench programming	This icon is not available.
	Results viewer	Open the Results Viewer.
	Curves viewer	Open the Curves Viewer.
	Statistics	Open the Statistics viewer.
	Connect	Establish connection between the device and the DeltaQC.
	Disconnect	Disconnect the device from the DeltaQC.
	Help	View the User Guides of DeltaQC products.


## Assembly Line area

The Assembly Line area contains the data stored in the local database (when working in Offline mode) and the data of the connected device (when working in Online mode).

## Assembly Line details area

The Assembly Line details area shows the details of the items selected in the Assembly Line area.

## Status bar



The status bar shows:

- the connection status between the device and DeltaQC.
- the battery level of the connected device: move the cursor on the battery symbol to display the charge level in percentage.
- information on the Pset parameters during the programming of the device with DeltaQC.

## Build area

The Build area provides the commands to create and manage Psets, Tools, Routes, Transducers.

## Log area

The Log viewer area displays information on the communication between the connected device and DeltaQC.

A “Log file” is automatically created in a subfolder of the installation directory of the DeltaQC (typically C:\Program Files\Desoutter\DeltaQC\Log).

- ⓘ A new file is created each day the software is used; the old files can be deleted.

## Search function

The DeltaQC is characterized by a search function, available to filter the various items (Psets, Tools, Routes, Transducers) displayed in the Assembly Line area.

To search items:

1. In the Assembly Line area, click on the Analog transducers/Pset/Tool/Route node.  
The section **Find transducers/parameter set/tool/route** is displayed in the Assembly Line Details area.
2. Enter the search criteria and click on the **Find** button.  
The results are displayed in the Assembly Line Details area.

- ⓘ The search function is case-sensitive and partial matching of the strings is supported. Select the *Match whole word* checkbox to disable the partial matching function.

## How to copy and paste a Pset/Route

1. In the Assembly Line area, expand the Pset/Route node and select the item to copy.
2. In the Management area, click on the **Copy** (📄) icon.
3. In the Assembly Line area, click on the Pset/Route node.
4. In the Management area click on the **Paste** (📄) icon.
5. In the dialog box, set the following parameters:
  - Number: select the number of the Pset/Route.  
By default, the Pset/Route number assigned is the first number available. It is not possible to use numbers already assigned to other Psets/Routes.
  - Name: type the name of the Pset/Route.
  - Description: type additional information on the Route. This field is displayed only for Routes.
  - Device type: by default, the device type is the same of the Pset/Route copied.

## How to delete a Pset/Route

1. In the Assembly Line area, expand the Pset/Route node and select the item to delete.
2. In the management area, click on the **Delete** (✖) icon.
3. From the dialog box that opens, click on **Yes** to confirm.

## How to delete multiple Psets/Routes

1. In the Assembly Line area, click on the Pset/Route node.
2. In the Management area click on the Select (☑) icon.
3. In the Pset/Route selection dialog box, select the Psets/Routes to delete.
  - ⓘ In the lower area of the dialog box, the **Select all** and the **Unselect all** buttons allow to select respectively all the available Psets/Routes and to unselect all the Psets/Routes.
4. In the Pset/Route selection pop-up, click on the Delete (✖) icon.
5. From the dialog box that opens, click on **Yes** to confirm.

## Working in Online mode

The DeltaQC Online mode is active when a device is connected to the PC where DeltaQC is installed.

The Online mode allows to define and transfer the test programs directly on the device, and provides shortcuts to the device configuration, results and curves viewers.

## Connecting a device for the first time

The connection between the DeltaQC and a device is done by USB cable.

1. Power ON the device and wait for it to start up.
2. Use the USB cable to connect the device to the USB port of the PC.
3. Launch DeltaQC software on the PC.
4. From the Build area, click on the Scan (🔍) icon.
5. In the Select target device dialog box, click on the **Scan** button.
6. From the list of available devices, click on the device to connect and then on the **Select** button.
- 7.

From the DeltaQC toolbar, click on the arrow of the **Connect** () icon and select USB to establish connection between the device and the software.

ⓘ

When the device is connected to DeltaQC, the **Connect** () icon is disabled and the Disconnect



() icon is enabled.

## Connecting a device

1. Power ON the device and wait for it to start up.
2. Use the USB cable to connect the device to the USB port of the PC.
3. Launch DeltaQC software on the PC.
- 4.

From the DeltaQC toolbar, click on the arrow of the **Connect** () icon and select USB to establish connection between the device and the software.

ⓘ

When the device is connected to DeltaQC, the **Connect** () icon is disabled and the Disconnect




() icon is enabled.

## Creating a Pset online





1. A new Pset can be created in two ways:
  - in the Build area, click on the **Parameter set** (⚙) icon.
  - in the Assembly Line area, right-click on the Pset node and then on **Create a new Pset...**

2. In the dialog box, set the following parameters:
  - Number: select the number of the Pset.  
By default, the Pset number assigned is the first number available. It is not possible to use numbers already assigned to other Psets.
  - Name: type the name of the Pset.
  - Device type: by default, the device type is the device connected to the PC.
3. Click on **OK**.
4. In the Assembly Line details area, select the **Control strategy** from the drop-down menu.
5. In the Assembly Line details area, select the **Parameters** tab and configure the strategy parameters.
 

 The parameters displayed change according to the Control Strategy selected and the device version.
6. In the Assembly Line details area, select the **Options** tab and configure the strategy optional parameters.
7. In the lower-right corner of the Assembly Line details area, click on the **Save** button.

## How to configure the controller parameters

 The controller setup via DeltaQC can be done only in Online mode.

1.  From the DeltaQC toolbar, click on the **Controller** (  ) icon.
2. From the drop-down menu, click on **Configuration**.
3. In the **General** area of the Configuration dialog box, configure the available parameters and click the **Save**  icon of each parameter.
4. In the **Settings** area of the Configuration dialog box, configure the available parameters and click the **Save**  icon of each parameter.

### Controller parameters

#### General

- Name: the name is the same displayed in the Assembly Line area. If necessary, change the name of the device in use.
- Date and time: the date and time displayed are those of the device menu and are associated to the tightening results and curves. Select a new date and time, or click on the refresh icon to set the same date and time of the PC connected to the device.
- Language: from the drop-down menu, select the language of the device.

#### Settings

- Results confirmation option: from the drop-down menu, select between:
  - Never: all the results are acquired.
  - Always: at the end of each test, a message asks if the result must be kept or discarded. If the result is discarded, the batch count (if enabled) is not incremented.
  - NOK only: at the end of each Not OK test, a message asks if the result must be kept or discarded. If the result is discarded, the batch count (if enabled) is not incremented.
- Curves confirmation option: from the drop-down menu, select between:
  - Never: all the curves are acquired.
  - Always: at the end of each test, a message asks if the curve must be kept or discarded.
  - NOK only: at the end of each Not OK test, a message asks if the curve must be kept or discarded.
- Batch increment condition: from the drop-down menu, select between:
  - OK: the batch number of a Pset is incremented only if the result is OK.

- OK + NOK: the batch number of a Pset is always incremented, regardless of the result.
- Batches running mode: from the drop-down menu, select between:
  - Reset mode: when a batch is quit, the batch count is reset. If selected, a warning message asking to confirm the exit from the Pset is shown on the Q-SHIELD display.
  - Restore mode: when a batch is quit, the batch count is not reset, and it is possible to continue the batch later. This parameter is available only for Quality Control strategies.
- Gyroscope overspeed: from the drop-down menu, select between:
  - Enable: a warning message is displayed on the device display when the maximum angular speed is exceeded during tightening operations. It is recommended to keep this parameter always enabled.
  - Disable: by exceeding the maximum angular speed, no warning message is shown on the device display.
- Source type: from the drop-down menu, select between:
  - Keyboard: the Pset is started by selecting it with the device keyboard.
  - Tag: the Pset is started automatically after attaching the end fitting tool to the device. The Pset to execute depends on the number written in the end fitting tool RFID TAG.
- Tag required: from the drop-down menu, select between:
  - Enable: the Pset is started only if the end fitting tool attached to the Q-SHIELD is programmed with a tag identifier that matches the Pset number.
  - Disable: the Pset is started without the tag identifier recognition. If the Source type is set to Tag, this parameter is always set to Enable.
- Tag identifier: number written in the RFID TAG of the end fitting tool plugged into the Q-SHIELD. Click on the refresh icon to update the parameter in case a new end fitting tool is plugged into the Q-SHIELD, or change the parameter by selecting a new number from the drop-down menu. The Tag identifier numbers range from 001 to 250.
- Change screw check: from the drop-down menu, select between:
  - Enable: a warning message is displayed on the Q-SHIELD display when the Change screw value is reached during the execution of a Pset.
  - Disable: by reaching the change screw value, no warning message is displayed on the Q-SHIELD display. If Disable is selected, a warning message is shown on DeltaQC informing the operator that during the operations the screw may be damaged without getting any feedback.
- Wrench power off [minutes]: from the drop-down menu, select between:
  - Disabled: when inactive, the Q-SHIELD does not power off.
  - 5-10-15-30: when inactive for the selected minutes, the Q-SHIELD powers off.

The Q-SHIELD is active in the following cases:

- the operator is navigating the items of the menu;
- a Pset or a Demo mode tightening is in execution;
- the Q-SHIELD is connected to DeltaQC.

- Display switch off [minutes]: from the drop-down menu, select between:
  - Disabled: when inactive, the Q-SHIELD display does not switch off.
  - 5-10-15-30: when inactive for the selected minutes, the Q-SHIELD display switches off.

The Q-SHIELD is active in the following cases:

- the operator is navigating the items of the menu;
- a Pset or a Demo mode tightening is in execution.

## How to transfer online data to the database

To transfer the information defined online (including test results and curves) to the local database:

1. From the DeltaQC menu list, select **Transfer > Device → PC** or click on the **Transfer Device --> PC**






() icon from the toolbar.

2. In the Device --> PC dialog box select the **Psets** tab.

3. Select the items (Pset(s), Results and Traces) to be transferred.

**i** Psets can be marked with different icons:

- : the Pset is already present in the database and it will overwrite the existing copy if some of its parameters have changed.
- : the Pset is not present in the database and can be added to the database.
- : the Pset cannot be transferred to the database because a Pset with the same name is already present in the database, but it is created for another device. To transfer it, rename the Pset.

4. Click on the **Save** button.

### How to reset the device memory

- 1.



From the DeltaQC toolbar, click on the **Controller** () icon.

2. From the drop-down menu, click on **Memory**.

The Memory settings dialog box allows to:

- Delete all the Psets that are stored on the device memory.
- Delete all the results that are stored on the device memory.
- Delete all the diagnostics that are stored on the device memory.
- Delete all the curves that are stored on the device memory.

### How to display the device information

- 1.



From the DeltaQC toolbar, click on the **Controller** () icon.

2. From the drop-down menu, click on **Information**.

The Device information dialog box displays the following information on the connected device:

- Serial number
- Firmware version
- Type
- Battery charge level

### How to display diagnostic reports

- 1.



From the DeltaQC toolbar, click on the **Controller** () icon.

2. From the drop-down menu, click on **Diagnostic**.

3. The Diagnostic dialog box displays the last 10 diagnostic reports, click on the diagnostic () icon to display the report.

**i** The icon is red when at least one test gave a NOK result; the icon is green when all tests gave OK/N.A. results.

4. Use the buttons in the upper area of the report to refresh, customize, print and save the report.

### Working in Offline mode

The DeltaQC Offline mode is active when no device is connected to the PC where DeltaQC is installed.

The Offline mode, allows to create all configurations in the Assembly Line area and, when the offline configuration is done, to transfer those configurations to the device by connecting it to the PC.

## Creating a Pset offline

1. A new Pset can be created in two ways:
  - in the Build area, click on the **Parameter set** (🔧) icon.
  - in the Assembly Line area, right-click on the Pset node and then on **Create a new Pset...**
2. In the dialog box, set the following parameters:
  - Number: select the number of the Pset.  
By default, the Pset number assigned is the first number available. It is not possible to use numbers already assigned to other Psets.
  - Name: type the name of the Pset.
  - Device type: from the drop-down menu, select the device for which the Pset is created.
3. Click on **OK**.
4. In the Assembly Line details area, select the **Control strategy** from the drop-down menu.
5. In the Assembly Line details area, select the **Parameters** tab and configure the strategy parameters.
  - ⓘ The parameters displayed change according to the Control Strategy selected.
6. In the Assembly Line details area, select the **Options** tab and configure the strategy optional parameters.
7. In the lower-right corner of the Assembly Line details area, click on the **Save** button.

## Route


The Route is used to select the test programs to be transferred to the device. It is possible to create various Routes (up to 32.000) to transfer multiple set of tests to the device.

Working offline, it is possible to create up to 32.000 test programs (Pset). The device can store up to 250 Psets.

### How to create a Route

1. A new Route can be created in two ways:
  - in the Build area, click on **Route** (🔧) icon.
  - in the Assembly Line area, right-click on Route and then click on **Create a new Route...**
2. In the dialog box, set the following parameters:
  - Number: select the number of the Route.  
By default, the Route number assigned is the first number available. It is not possible to use numbers already assigned to other Routes.
  - Name: type the name of the Route.
  - Description: type additional information on the Route.
  - Device type: from the drop-down list, select the target device.
3. Click on **OK**.
4. The Route created is displayed in the **General** tab of the Assembly Line details area.
5. In the Assembly Line details area, select the **Linked Pset/Tools** tab to configure the Route.
6. Click on the Pset icon (🔧) to add one or more Pset to the Route.

7. The following Pset selection dialog box is displayed:



A	Confirm Pset selection	B	Cancel Pset selection
C	Clear filters	D	Find Pset
E	Search by Pset name	F	Search by Pset number
G	Pset check boxes		

Select the check boxes next to the Pset and click on the **Confirm** button to add the Pset to the Route.

**i** Use the Search bar placed in the bottom area of the dialog box to filter by name and/or number the list of Pset displayed. The search by name is case-sensitive.

8. The selected Pset are displayed in the **Linked Pset/Tools** tab of the Assembly Line details area.


If necessary, select a Pset and click on the Delete (🗑️) icon to remove it from the Route, or use the navigation arrows (⏪ ⏩) icons to change the order of the Pset in the Route.

9. In the lower-right corner of the Assembly Line details area, click on the **Save** button.

### How to transfer a Route to the device

1. Power ON the device and wait for it to start up.
2. Use the USB cable to connect the device to the USB port of the PC.
3. From the DeltaQC menu list, select **Transfer > Device → PC** or click on the **Transfer PC --> Device**



() icon from the toolbar.

4. In the PC --> Device dialog box select the **Route of Pset** tab.
5. From the Device type drop-down menu, select the device.  
The Routes created for the selected device type are displayed.
6. Select the check box of the Route to transfer.

**i** The maximum number of routes to be selected is 1.

7. Click on the **Save** button to send the Route to the device.

**i** When a Route is sent to the device, all the Psets stored in the device memory are deleted. To keep a copy of the existing Psets stored in the device, the Psets must be saved in the database before transferring the Route from the PC to the device (for more information, refer to *How to transfer online data to the database [Page 10]*).

### How to export Routes

1. In the Assembly Line area, click on the Route node.
2. In the Management area, click on the **Export** (📄) icon.

3. In the Export - Routes selection dialog box, select the Route(s) to export.
  - ⓘ In the lower area of the dialog box, the **Select all** and the **Unselect all** buttons allow to select respectively all the available Routes and to unselect all the Routes.
4. In the Export - Routes selection dialog box, click on the **Export** (📄) button and save the Psets in the PC as an XML file.
  - ⓘ It is also possible to export Routes by right-clicking on the Route node in the Assembly Line area and then on **Export...**

### How to import Routes

- ⓘ The import of Routes can be done only in Offline mode. Before proceeding with the import, from the DeltaQC toolbar click on the Disconnect icon to disconnect the Q-SHIELD from the PC.
1. In the Assembly Line area, click on the Route node.
  2. In the Management area, click on the **Import** (📄) icon.
  3. Select the XML file from the PC files.
  4. In the Import – Route selection dialog box, select the Route(s) to import.
    - ⓘ In the lower area of the dialog box, the **Select all** and the **Unselect all** buttons allow to select respectively all the available Routes and to unselect all the Routes.
    - ⓘ The **Notes** column (last column of the table) shows details about the Routes:
      - If a Route is marked in green as “New”, there is no existing match in the destination database and it possible to import the Route.
      - If a Route is marked in light green as “Existent”, a Route with the same name but different configuration already exists in the destination database, and the Route imported will overwrite the existing one.
      - If a Route is marked in red as “Duplicated”, a Route with the same name but linked to a different device already exists in the destination database and it is not possible to import it.
  5. In the Import – Route selection dialog box, click on the **Import** (📄) button.
    - ⓘ It is also possible to import Routes by right-clicking on the Route node in the Assembly Line area and then on **Import...**

### How to create a database backup file

1. From the DeltaQC menu list, click on **File > Database > Create a backup**.
2. In the Database - Create a backup dialog box, click on the **Folder** button.
3. Select or create the destination folder and click on the **OK** button.
4. In the Database - Create a backup dialog box, click on the **Create** button.
 

At the end of the process, a confirmation message informs that the database backup file is created with success.

### How to restore a database backup file

1. From the DeltaQC menu list, click on **File > Database > Restore a backup**.
2. In the Database - Restore a backup dialog box, click on the **Database file** button
3. Select the database to import.
4. In the Database - Restore a backup dialog box, click on the **Restore** button.
  - ⓘ If the database to restore is characterized by a version higher than the destination database, it is marked in red and it is not possible to restore it.
 

Upgrade DeltaQC Software to the latest version in order to complete the operation.
  - ⓘ If the database to restore is characterized by a version lower than the database current version, it is marked in yellow.
 

Click on the **Restore** button and follow the procedure to perform the migration of the database and complete the operation.

At the end of the process, a confirmation message informs that the database backup file is restored with success.

## How to export one or more Psets

1. In the Assembly Line area, click on the Pset node.
2. In the Management area, click on the Export (📄) icon.
3. In the Export - Psets selection dialog box, select the Pset(s) to export.
  - ❗ In the lower area of the dialog box, the **Select all** and the **Unselect all** buttons allow to select respectively all the available Psets and to unselect all the Psets.
4. In the Export - Psets selection dialog box, click on the **Export** (📄) button and save the Psets in the PC as an XML file.
  - ❗ It is also possible to export Psets by right-clicking on the Pset node in the Assembly Line area and then on **Export...**

## How to import one or more Psets

- ❗ The import of Psets can be done only in Offline mode. Before proceeding with the import, from the DeltaQC toolbar click on the Disconnect icon to disconnect the Q-SHIELD from the PC.
1. In the Assembly Line area, click on the Pset node.
  2. In the Management area, click on the **Import** (📄) icon.
  3. Select the XML file from the PC files.
  4. In the Import – Pset selection dialog box, select the Pset(s) to import.
    - ❗ In the lower area of the dialog box, the **Select all** and the **Unselect all** buttons allow to select respectively all the available Psets and to unselect all the Psets.
    - ❗ The **Notes** column (last column of the table) shows details about the Psets (see figure below):
      - If a Pset is marked in green as “New”, there is no existing match in the destination database and it is possible to import the Pset.
      - If a Pset is marked in light green as “Existent”, a Pset with the same name but different configuration already exists in the destination database, and the Pset imported will overwrite the existing one.
      - If a Pset is marked in red as “Duplicated”, a Pset with the same name but linked to a different device already exists in the destination database and it is not possible to import it.
  5. In the Import – Pset selection dialog box, click on the **Import** (📄) button.
    - ❗ It is also possible to import Psets by right-clicking on the Pset node in the Assembly Line area and then on **Import...**

## Results viewer

The Results Viewer allows the user to retrieve the results from the Q-SHIELD or from the database. The Q-SHIELD can store up to 1000 results; when the memory is full, the new results overwrite the oldest results stored.

The results can be viewed in two ways:

- Online: to view the results stored on the device by connecting the device to the DeltaQC.
- Offline: to view the results downloaded from the device and stored in the database.


## How to view the results

- 1.



From the DeltaQC toolbar, click on the Results Viewer (📄) icon.

2. The following Results Selection dialog box is displayed:



A Select the Device type from the drop-down list.

**i** When working in Online mode, the device type is the device connected to the PC.

C Psets checkboxes

B Select all Psets displayed / Unselect all Psets displayed

D Find Pset according to: Name, Strategy, Transducer SN, date from - date to.

**i** The search function is case-sensitive and partial matching of the strings is supported. Select the *Match whole word* checkbox to disable the partial matching function.

E Find: click to apply the selected filters / Clear: clear the filters applied.

Select the check boxes of the Psets and click on **OK** to display the results.

3. The following results page is displayed:

Result ID	Status	Date & Time	Pset ID	Pset Name	Strategy	Test Type	Unit of Measure	Torque Status	Torque Result
102	OK	28-04-2020 19:01:36	1	test Qshield S 1	Production: Torque Time	CM/CMK	Nm	OK	7.799
101	OK	28-04-2020 19:01:26	1	test Qshield S 1	Production: Torque Time	CM/CMK	Nm	OK	9.209
100	OK	28-04-2020 18:35:16	1	test Qshield S 1	Production: Torque Time	CM/CMK	Nm	OK	6.920
99	OK	28-04-2020 18:35:07	1	test Qshield S 1	Production: Torque Time	CM/CMK	Nm	OK	7.120
98	OK	28-04-2020 18:25:16	1	test Qshield S 1	Production: Torque Time	CM/CMK	Nm	OK	6.641
97	NOK	28-04-2020 18:16:38	1	test Qshield S 1	Production: Torque Time	CM/CMK	Nm	HIGH	13.89
96	OK	28-04-2020 17:53:58	1	test Qshield S 1	Production: Torque Time	CM/CMK	Nm	OK	5.456
95	OK	28-04-2020 17:47:36	1	test Qshield S 1	Production: Torque Time	CM/CMK	Nm	OK	9.489
94	NOK	28-04-2020 17:35:50	1	test Qshield S 1	Production: Torque Time	CM/CMK	Nm	LOW	3.154
93	NOK	28-04-2020 17:35:42	1	test Qshield S 1	Production: Torque Time	CM/CMK	Nm	LOW	-0.040
92	NOK	28-04-2020 17:16:06	1	test Qshield S 1	Production: Torque Time	CM/CMK	Nm	LOW	-0.679
91	NOK	28-04-2020 17:16:06	1	test Qshield S 1	Production: Torque Time	CM/CMK	Nm	LOW	-0.426
90	NOK	28-04-2020 17:16:06	1	test Qshield S 1	Production: Torque Time	CM/CMK	Nm	LOW	-0.373
89	NOK	28-04-2020 17:16:05	1	test Qshield S 1	Production: Torque Time	CM/CMK	Nm	LOW	-0.586
88	NOK	28-04-2020 17:16:05	1	test Qshield S 1	Production: Torque Time	CM/CMK	Nm	LOW	-0.186
87	NOK	28-04-2020 17:16:05	1	test Qshield S 1	Production: Torque Time	CM/CMK	Nm	LOW	-0.825
86	NOK	28-04-2020 17:16:05	1	test Qshield S 1	Production: Torque Time	CM/CMK	Nm	LOW	-0.027
85	NOK	28-04-2020 17:16:03	1	test Qshield S 1	Production: Torque Time	CM/CMK	Nm	LOW	-0.532
84	NOK	28-04-2020 17:16:03	1	test Qshield S 1	Production: Torque Time	CM/CMK	Nm	LOW	-0.732
83	NOK	28-04-2020 17:16:02	1	test Qshield S 1	Production: Torque Time	CM/CMK	Nm	LOW	-0.838
82	NOK	28-04-2020 17:16:02	1	test Qshield S 1	Production: Torque Time	CM/CMK	Nm	LOW	-0.652
81	NOK	28-04-2020 17:16:01	1	test Qshield S 1	Production: Torque Time	CM/CMK	Nm	LOW	-0.732

- A Select all the results / Unselect all the results.
- B From the drop-down list, select the filter to apply to the results among: No Filter, Status OK, Status KO, Torque status OK, Torque status KO, Angle status OK, Angle status KO.
- C Delete the selected results.
- D Export the selected results in an Excel file.
- E Pset filter: click to open the Result Selection dialog box.
- F Progress bar displaying the advancement of the results downloaded.
- G Number of results found.
- H Close the Results Viewer window.
- I Click on a column headline to organize the results according to the ascending/descending order of the selected column.
- L Results check boxes: select/unselect results.

### Curves viewer


The Curves Viewer allows the user to retrieve the curves from the Q-SHIELD or from the database. The Q-SHIELD can store up to 25 curves (the maximum time length allowed for each curve is 30 seconds); when the memory is full, the new curves overwrite the oldest curves stored.

The curves can be viewed in two ways:


- Online: to view the curves stored on the device by connecting the device to the DeltaQC.
- Offline: to view the curves downloaded from the device and stored in the database.

### How to view curves

1.

From the DeltaQC toolbar, click on the Curves Viewer () icon.

2. The following Curve Selection dialog box is displayed:




- |   |   |   |   |
|---|---|---|---|
| A | Select the Device type from the drop-down list.   | B | Psets checkbox  |
|   | <p><b>i</b> When working in Online mode, the device type is the device connected to the PC.</p>   |   |   |
| C | Find Pset according to: Name, Strategy, date from - date to.  | D | Find: click to apply the selected filters.<br>Clear: clear the filters applied. |
|   | <p><b>i</b> The search function is case-sensitive and partial matching of the strings is supported. Select the <i>Match whole word</i> checkbox to disable the partial matching function.</p> |   |   |

Select the check boxes of the Psets for which curves are available and click on **OK** to display the curves.

- i** It is possible to select up to 25 curves.

3. The following Curves Viewer window is displayed:



<p>A Refresh the curves displayed when a new curve is available.</p> <p><b>i</b> Available only when working in Online mode.</p>	<p>B Compare the available curves.</p> <p><b>i</b> For more information, refer to <i>How to compare curves [Page 19]</i>.</p>
<p>C Curves selected in Offline mode or acquired in Online mode.</p> <p><b>i</b> When working in Online mode, the last curve acquired is marked as "Curve x LAST".</p>	<p>D Show cursor / Hide cursor: click to show/hide data on the curve when moving the cursor on the chart.</p>
<p>E Export the curve chart in a .jpg file.</p>	<p>F Export the curve values in an Excel file.</p>
<p>G Export a report of the curve in a PDF, Excel or Word file.</p>	<p>H Delete curve</p> <p><b>i</b> Available only when working in Offline mode.</p>
<p>I Close the Curves Viewer window.</p>	<p>L Curve chart.</p>
<p>M Curve type / Limits / Results: select what to view in the chart.</p> <p><b>i</b> If the result is Not OK, it is marked on the curve with a red X.</p>	<p>N General information, angle parameters and torque parameters of the curve.</p>

To zoom in on a specific region of the graph: position the mouse at the left edge of the area required, left-click and move the mouse down/rightward as to draw the area to zoom, then release the mouse button.

To navigate the zoomed in curve, right-click and move the mouse.


To zoom out: position the mouse on any area of the chart, left-click and move the mouse up/leftward, then release the mouse button.

### How to compare curves

The comparison of curves allows to overlap the selected curves and compare tightening operations.

**i** For more information on how to select curves, refer to *How to view curves [Page 17]*.

1. From the Curves Viewer window, click on the **Compare** button.
2. The following window is displayed:



<p>A Refresh the curves displayed when a new curve is available.</p> <p><b>i</b> Available only when working in Online mode.</p>	<p>B Curves included in the comparison.</p>
<p>C Curve type: from the drop-down list, select the type of curve to display in the chart.</p>	<p>D Export the curves chart in a .jpg file.</p>
<p>E Export a report of the curves comparison in a PDF, Excel or Word file.</p>	<p>F Close the Curves Viewer window.</p>
<p>G Curves comparison chart.</p>	<p>H General information, angle parameters and torque parameters of the curve: click on the + or - to expand or collapse the nodes.</p>
<p>I Curves list: select/unselect the check boxes of the curves to compare.</p>	

## Statistics

The statistics can be created in two ways:

- Online: to view the statistics of the results stored on the device by connecting the device to the DeltaQC.
- Offline: to view the statistics of the results downloaded from the device and stored in the database.

## How to create statistics


- 1.



From the DeltaQC toolbar, click on the Statistics ( ) icon.

2. In the General tab of the Statistics page, configure the following parameters:
  - Device: from the drop-down menu, select the device.  
When working in Online mode, the Device type is set to the device connected to the PC.
  - Measure: select between Torque or Angle.
  - Test: set by default to Quality/Production.
  - Check: select between Cmk/Cpk and SPC.
  - Standard: from the drop-down menu, select between: ISO (3534-2:2006), CNOMO (E41.32.110N), NF (E 60-181), Normal Distribution Test (Shapiro-Wilk), Normal Distribution Test (Chi-Squared), Q544000:1990, Q544000:2004.
  - Parameters: type the expected values for Cm, Cmk, Cp, Cpk.  
Only the parameters applicable to the Test and Standard selected are available.
3. Select the Results tab of the Statistics page. Then, select the following items:
  - Psets: select the Pset results to use in the statistic.
  - Batches: select one or more batches containing the results of the tests executed with the selected Pset.  
Multiple selection is allowed only for batches with same size.
  - Results: select the results to include in the statistic.  
To select or unselect all the results listed, right-click on a row and click on Select all.../Unselect all...

ⓘ Results with one of the following messages displayed in the Result details column, cannot be selected and included in the statistic: Peak Not Detected, Yield Point Not Detected, Overload Detected, Rehit Detected, Overspeed Detected, Batch Increment, Batch Decrement, Not Detected.
4. Select the Values tab of the Statistics page. The values of the selected results are displayed and by right-clicking on a row it is possible to copy to the clipboard the selected values.
5. Select the Statistics tab of the Statistics page. The statistics generated according to the selected standard are displayed:




A	Statistics tab	B	Close the Statistics Viewer
C	Statistics according to the selected standard	D	Remarks
E	Available charts and reports		

6. Click on the **Graphic display** / **Capability chart** / **Histogram** / **Control chart** buttons to display the respective charts and to save, print, or create a report of the statistics.  
For more information, refer to *Statistics charts and reports [Page 21]*.

## Statistics charts and reports

### Graphical display


The graphical display shows all the results versus the date of the test:



- A Display and print/export the statistics report in an Excel, PDF or Word file.
- B Save the Graphical display in a JPEG file.
- C Print the Graphical display.

### Capability chart


The Capability chart shows all the results in sequence:



- A Display and print/export the statistics report in an Excel, PDF or Word file.
- B Save the Capability chart in a JPEG file.
- C Print the Capability chart.

### Histogram

The Histogram shows all the results in a histogram chart detailing how many results fall into a certain interval:




- A
- B
- C

- |   |   |   |                                    |
|---|---|---|------------------------------------|
| A | Display and print/export the statistics report in an Excel, PDF or Word file. | B | Save the Histogram in a JPEG file. |
| C | Print the Histogram.  |   |                                    |

### Control chart

The Control chart shows the X,R charts for the statistic control tests:



- |   |  |   |   |
|---|--|---|---|
| A | Select the statistic control rules to apply. | B | Remarks   |
| C | Corrective action(s).                        | D | Print the Control chart.  |
| E | Save the Control chart in a JPEG file.       | F | Display and print/export the statistics report in an Excel, PDF or Word file. |

## References

### Tightening strategies

Tightening strategies can be divided into two main categories:

- Production: strategies for tightening a screw.
- Quality Control: strategies for evaluating residual torque.

### Production strategies

Production strategies can be divided into three main categories:

- **Tightening within torque limits:** this is the easiest tightening method, it is enough applying torque within the limits.




Illustration 1: Torque vs. Time

A	Upper torque limit	B	Nominal
C	Lower torque limit		

- **Tightening within torque and angle limits:** this is a more accurate way to tighten, because an additional information (angle) is used during the tightening process.





Illustration 2: Torque vs. Angle

A	Upper torque limit	B	Nominal
C	Lower torque limit	D	Lower angle limit
E	Upper angle limit		

Using this method, it is possible to detect potential problems on the joint (refer to the following examples):


Torque is correct, but angle is too small:

- Misalignment problem
- The hole is not completely threaded (or it is not deep enough)
- The bolt is stopped by oil in a dead hole
- There is dirt in the threads
- The threads are damaged
- The screw is already tightened



Angle is correct, but torque is too low:

- The thread may be stripped out
- The screw is too soft (tightened over yield)
- Unexpected low  $\mu$  (friction coefficient)



- **Tightening with torque and additional angle rotation (torque + angle):** the bolt is first tightened to a certain torque and then it is further tightened to a specific angle. The goal is to stress the bolt over the yield point. Even with differences in the angle, the torque (causing clamping force) is quite reliable. Sometimes the joint is specially designed and the analysis of the joint helps making sure that strain is far away from the breaking point.




Illustration 3: Torque vs. Angle

### Torque Time

This strategy leads the operator in reaching the desired target torque, without any angle reading. It is enough to define the Cycle start, Minimum torque, Target torque, Maximum torque and the Change screw at parameters.




Illustration 4: Torque vs. Time

A	Change screw at	B	Max. torque
C	Target torque	D	Min. torque
E	Cycle start		

The green area identifies the OK result area. If the torque goes over the Change screw value, a message informing the operator to replace the screws is shown on the Q-SHIELD display.

The torque result is the maximum torque value measured during the tightening.

The Q-SHIELD display background is colored as follows:

- Blue: default color for Pset execution.
- Green: the test ends with OK result.
- Red: torque over the maximum limits.

For information on the vibration behavior, refer to *Vibration parameter [Page 39]*.

### Torque & Angle

This strategy leads the operator in reaching the desired target torque while monitoring the angle. The Angle threshold parameter is the threshold from which to start angle measurement (normally set to 50% of the Target Torque).




Illustration 5: Torque vs. Angle

A	Change screw at	B	Max. torque
C	Target torque	D	Min. torque
E	Angle threshold	F	Cycle start

The green area identifies the OK result area. If the torque goes over the Change screw value, a message informing the operator to replace the screws is shown on the Q-SHIELD display.

Torque/angle results:

- If the torque/angle does not go over the torque/angle limits, the result is taken at the torque peak or angle peak as specified in the Pset options.
- If the torque/angle goes over the limit, the result is taken as follows:




Illustration 6: Torque vs. Angle

A	Max. torque	B	Min. torque
C	Angle threshold	D	Cycle start
E	Min. angle	F	Max. angle
G	When the <b>Measure peak at</b> option is set to Torque, and the torque (or both torque and angle) goes over the limits, the result is taken at the Torque peak.	H	When the <b>Measure peak at</b> option is set to Torque, and only the angle goes over the limits, the result is taken at the Angle peak.




Illustration 7: Torque vs. Angle

A	Max. torque	B	Min. torque
C	Angle threshold	D	Cycle start
E	Min. angle	F	Max. angle
G	When the <b>Measure peak at</b> option is set to Angle, and the angle (or both torque and angle) go over the limits, the result is taken at the Angle peak.	H	When the <b>Measure peak at</b> option is set to Angle, and only the torque goes over the limits, the result is taken at the Torque peak.

The Q-SHIELD display background is colored as follows:

- Blue: default color for Pset execution.
- Green: the test ends with OK result.
- Red: torque and/or angle over the maximum limits.

For information on the vibration behavior, refer to *Vibration parameter [Page 39]*.

### Torque + Angle

This strategy guides to operator in reaching the desired target angle while monitoring the torque. The Angle threshold parameter is the threshold from which to start angle measurement (normally set to 50% of the Target Angle).




Illustration 8: Torque vs. Angle

A	Change screw at	B	Max. torque
C	Target torque	D	Min. torque
E	Angle threshold	F	Cycle start
G	Min. angle	H	Target angle
I	Max. angle		

This strategy is similar to Torque & Angle; the Target Angle value is required instead of the Target Torque, and the progressive bar increases with the angle and not with the torque.

Torque/angle results:

- If the torque/angle does not go over the torque/angle limits, the result is taken at the torque peak or angle peak as specified in the Pset options.
- If the torque/angle goes over the limit, the result is taken as follow:




Illustration 9: Torque vs. Angle

A	Max. torque	B	Min. torque
C	Angle threshold	D	Cycle start
E	Min. angle	F	Max. angle
G	When the <b>Measure peak at</b> option is set to Torque, and the torque (or both torque and angle) goes over the limits, the result is taken at the Torque peak.	H	When the <b>Measure peak at</b> option is set to Torque, and only the angle goes over the limits, the result is taken at the Angle peak.




Illustration 10: Torque vs. Angle

A	Max. torque	B	Min. torque
C	Angle threshold	D	Cycle start
E	Min. angle	F	Max. angle
G	When the <b>Measure peak at</b> option is set to Angle, and the angle (or both torque and angle) go over the limits, the result is taken at the Angle peak.	H	When the <b>Measure peak at</b> option is set to Angle, and only the torque goes over the limits, the result is taken at the Torque peak.

The Q-SHIELD display background is colored as follows:

- Blue: default color for Pset execution.
- Green: the test ends with OK result.
- Red: torque and/or angle over the maximum limits.

For information on the vibration behavior, refer to *Vibration parameter [Page 39]*.

### Prevailing Torque Automatic Compensation

The purpose of the strategy is to reach the desired Target torque and to verify whether torque values result within configured limits during a pre-established angle interval.




Illustration 11: Torque vs. Angle

A	Final Max. torque	B	Final Target torque
C	Final Min. torque	D	Prevailing Max. torque
E	Prevailing Min. torque	F	Prevailing Min. angle



C	Min. torque	D	Angle threshold
E	Cycle start	F	Breakaway point
G	Residual torque	H	Breakaway point
I	Residual torque		

CASE A (chart on the left): Normally there is a rapid change of the gradient of the torque/angle function when the bolt starts moving.

CASE B (chart on the right): Sometimes, due to high static friction built into the joint (for instance, for no lubrication, conical seat) as soon as the bolt moves the torque decreases, and the real residual torque is lower than the peak torque necessary to overcome the static friction.

**i** In both the above cases, the algorithm detects automatically the correct breakaway point.

Min. torque and Max. torque define the torque limits where the result is considered as OK. The Angle threshold, that must be greater than the Cycle start, defines the point from which the Q-SHIELD starts measuring the angle.

If during the residual torque check the operator goes over the Change Screw value, a message is shown on the Q-SHIELD display to indicate that the screw must be replaced with a new one.

Torque results:

- If the breakaway point is detected, the result is the Residual torque.
- If the breakaway point is not detected (or if the torque goes over the Change Screw value) the result is the Max. torque measured.

The Q-SHIELD display background is colored as follows:

- Blue: default color for Pset execution.
- Green: the residual torque measured is between the minimum and maximum torque.
- Red: the residual torque is either below the minimum or over the maximum torque, or the residual torque point is not detected.

For information on the vibration behavior, refer to *Vibration parameter [Page 39]*.

### **Residual Torque/Angle**

This strategy evaluates the residual torque on a joint, measuring the torque necessary to rotate the screw further.




Illustration 13: Torque vs. Angle

A	Change screw at	B	Max. torque
C	Min. torque	D	Angle threshold
E	Cycle start	F	Target angle
G	Residual torque		

Min. torque and Max. torque define the torque limits where the result is considered as OK. The Angle threshold, that must be greater than the Cycle start, defines the point from which the Q-SHIELD starts measuring the angle. The recommended values are Target Angle set to 2 degrees and the Angle Threshold set to the 50% of the expected

residual torque.

If during the residual torque check the operator goes over the Change Screw value, a message is shown on the Q-SHIELD display to indicate that the screw must be replaced with a new one.

Torque result:

- If the target angle is reached, the result is the torque measured at the target angle,
- If the target angle is not reached (or if the torque goes over the Change Screw value), the result is the Max. torque measured.

The Q-SHIELD display background is colored as follows:

- Blue: default color for Pset execution.
- Green: the residual torque measured is between the minimum and maximum torque.
- Red: the residual torque is either below the minimum or over the maximum torque, or the residual torque point is not detected.

For information on the vibration behavior, refer to *Vibration parameter [Page 39]*.

### Residual Peak/Torque

This strategy evaluates the residual torque on a joint as the peak of the torque necessary to rotate the screw further.




Illustration 14: Torque vs. Angle

A	Change screw at	B	Max. torque
C	Min. torque	D	Cycle start
E	Torque peak		

**i** The result of this strategy is affected by the operator movement; it is important to release the torque as soon as the screw starts moving.

In this strategy, user can select a checkbox to enable angle reading during the test.

- When selected, user can set an **Angle threshold**.
- User can also enter an **Angle correction coefficient (Deg)**, if needed.

If the **Calculate the angle** option is selected:

- The Q-SHIELD display shows the angle in real time during the test.
- The result and trace include the angle value detected at the torque peak.

The Q-SHIELD display background is colored as follows:

- Blue: default color for Pset execution.
- Green: the torque peak is between the minimum and maximum torque.
- Red: the torque peak is below the minimum or over the maximum torque.

### Drag Torque

The purpose of the present strategy is to verify that the value of the Drag torque type (Minimum, Maximum or Average) results within configured torque limits during a pre-established angle interval.




Illustration 15: Torque vs. Angle

A	Change screw at	B	Max. torque
C	Min. torque	D	Angle threshold
E	Cycle start	F	Start angle
G	Stop angle	H	Drag torque

Torque/Angle results:

- If the value of the chosen Drag torque type (Minimum, Maximum or Average) falls within the established torque and angle interval, the result is OK.
- If the value of the chosen Drag torque type (Minimum, Maximum or Average) does not fall within the established torque and angle interval, the result is NOK.

The Q-SHIELD display background is colored as follows:

- Blue: default color for Pset execution.
- Green: the Drag torque (Minimum, Maximum or Average) at the Stop angle is between the minimum and maximum torque.
- Red: torque result is below the minimum or over the maximum torque.

For information on the vibration behavior, refer to *Vibration parameter [Page 39]*.

Algorithm used to detect the yield point:

The torque/angle trace is sampled at 1 kHz. Several Torque and angle values  $T_i$  and  $A_i$  are calculated as moving averages of 128 torque/angle samples measured by the Q-SHIELD. This means that for each next value acquired, new  $T_i$  and  $A_i$  values are calculated:

10  $T_i$  and  $A_i$  values are considered step by step to calculate the following parameters:

- Sum of the torque values
- Sum of the angle values
- Sum of torque values multiplied by angle values
- Sum of the square of the angle values

From these terms calculated above, linear regression is applied to obtain the gradient of the torque/angle trace:

The gradient  $\alpha_t$  is recalculated by linear regression each next sample acquired, and the average of 20 different values  $\alpha_t$  is calculated.

This average is also recalculated sample by sample. If 30 consecutive values of this  $\alpha$  average (absolute value) are not greater than a threshold value of the Linear slope Coefficient (LSC) multiplied by 0.4, and for 2 degrees they stay under the Linear slope Coefficient multiplied by 1.6, the yield point is considered to have been detected.

### Yield Point

The purpose of the strategy is to detect the Yield point of the joint under analysis that is the bolt elastic limit (yield).




Illustration 16: Torque vs. Angle

A	Change screw at	B	Max. torque
C	Min. torque	D	Angle threshold
E	Cycle start	F	Yield point

❶ It is recommended to reach the Yield Point with a single tightening; ratcheting is allowed if it is done at the 50 ÷ 60 % (MAXIMUM) of the supposed Yield Point.

In order to investigate the elastic characteristic of the bolt the Pset should be configured in this way:

The Cycle start must be set at least to 10% of the supposed Yield point.

The Angle threshold, that must be greater than the Cycle start, defines the point from which the Q-SHIELD starts measuring the angle.

The Min torque and the Max torque define the torque limits within which the value of the Yield point detected will be considered as OK.

Furthermore is necessary to set an appropriated coefficient, the Linear Slope Coefficient (LSC). This parameter is active only for the Yield Point strategy, and characterizes the joint stiffness in the linear part of the curve, as torque/angle slope in the Nm/° measurement unit. In other terms, the LSC is the slope of the torque/angle characteristic of the joint in the first part (linear). The minimum value is 0.1, which suits also very soft joints with a ration smaller than 0.1. The default value is 0.5. The Linear slope coefficient may be calculated experimentally for each single joint (only after executing a trial test to get data for calculating it) as follows:




Illustration 17: Torque vs. Angle

$$\frac{\Delta T}{\Delta A} = \frac{T_2 - T_1}{A_2 - A_1} = \text{Linear slope coefficient}$$

- ⓘ If the unit of measurement used is different from Nm, the Linear slope Coefficient must be converted to Nm/°. For instance, for a joint with a stiffness of 0.6 lbf\*ft/°, since 1 lbf\*ft = 1.3558 Nm, the Linear Slope Coefficient must be converted to:

$$0.6 \text{ lbf*ft/}^\circ \rightarrow 0.6 \times 1.3558 = 0.81 \text{ Nm/}^\circ$$

With this strategy, the wrench detects the yield point automatically and, depending on the specified torque limits range, the Torque result may be one of the following options:

- If the Yield Point is detected (within torque limits), the result is taken at the Yield Point.
- If the Yield Point is not detected, the result is the torque peak.
- If the torque goes over the Change Screw value, the Yield Point is no longer detected and the torque result is the torque peak.

The Q-SHIELD display background is colored as follows:

- Blue: default color for Pset execution.
- Green: the Yield point is detected within torque limits.
- Red: the Yield point is below or above the torque limits or not detected.

For information on the vibration behavior, refer to *Vibration parameter [Page 39]*.

The Algorithm used to detect the yield point is the following:

The torque/angle trace is sampled at 1 kHz.

Several torque and angle values  $T_i$  and  $A_i$  are calculated as moving averages of 128 torque/angle samples measured by the wrench. This means that for each next value acquired, new  $T_i$  and  $A_i$  values are calculated:

10  $T_i$  and  $A_i$  values are considered step by step to calculate the following parameters:

- Sum of the torque values
- Sum of the angle values
- Sum of torque values multiplied by angle values
- Sum of the square of the angle values

From these terms calculated above, linear regression is applied to obtain the gradient of the torque/angle trace:


The gradient  $\alpha_t$  is recalculated by linear regression each next sample acquired, and the average of 20 different values  $\alpha_t$  is calculated.

This average is also recalculated sample by sample. If 30 consecutive values of this  $\alpha$  average (absolute value) are not greater than a threshold value of the Linear slope Coefficient (LSC) multiplied by 0.4, and for 2 degrees they stay under the Linear slope Coefficient multiplied by 1.6, the yield point is considered to have been detected.

### **Residual Loose and Tighten**

The purpose of this strategy is to loosen the bolt up to a target angle, and to tighten it back to the original Zero position.

In the first stage of the strategy, the operator unscrews the bolt for a few degrees; in the second stage of the strategy, the operator screws the bolt back to the starting position.



- ⓘ Set the Target Angle to a few degrees, so that the torque during the loosening phase does not fall under the Cycle start value.

The residual torque result is the torque at the end of the tightening operation (measured when the original Zero position is reached back).

Results:

- If the original Zero position is reached within 30s and within the torque limits, the result of the test is OK; the torque result is the torque measured at the Zero position and the angle result is equal to zero.
- If the Zero position is not reached within 30s, the result of the test is NOK; the angle result is negative and the torque result is the last torque value measured.
- If the Zero position is reached within torque limits, but the Peak torque is over the Change screw value, the result is NOK.

During the loosening phase of the strategy, the Q-SHIELD display background is colored as follows:

- Blue: default color for Pset execution.
- Green: the Target angle of the loosening process is reached (when the tightening phase starts, the green led switches off).
- Red: the Target angle is not reached, or reached but 30s timeout expire; the tightening operation starts before the Target angle is reached.

During the re-tightening phase of the strategy, the Q-SHIELD display background is colored as follows:

- Blue: default color for Pset execution.
- Green: the Loose and Tighten process is successfully completed within Torque limits.
- Red: the loosening and tightening process is completed but the torque result is below or above the torque limit, or over the Change screw value; the re-tightening operation started before the Target angle was reached; the 30s timeout expires.

For information on the vibration behavior, refer to *Vibration parameter [Page 39]*.

### **Minimum after breakaway**

The Minimum after breakaway strategy is ideal to find the residual torque in curves with not coinciding breakaway and residual points.

The strategy aims to search a local minimum within the angle interval set by the user (Residual angle threshold 1 and Residual angle threshold 2).

When the Residual angle threshold 2 is surpassed, the measuring interval is over and if a candidate residual point was found, it is chosen as result.

Otherwise, the maximum torque measured during the cycle will be shown on the display, and the result will be Not detected.

For a proper residual detection, make sure that the breakaway and residual points are included in the angle interval (Residual angle threshold 1 and Residual angle threshold 2), and that the Residual angle threshold 2 is reached and surpassed during the check.

### **Residual intersection**

The Residual intersection strategy is ideal to find the residual torque in curves with coinciding breakaway and residual points.

How the strategy works:

During the check the intersection points of the curve with Residual angle threshold 1, 2, 3, and 4 are stored.

When the angle level surpasses Residual angle threshold 4, the operator is warned that the tightening can stop.

The four points torque and angle values are used as coordinates to find two lines passing through them (the first two points identify the first line, the third and fourth points the second one). The intersection of the two lines is considered the residual point.

### **Slope change**

The slope change strategy can find the residual torque in either curves with coinciding breakaway and residual points or with not coinciding ones.

The result is obtained after a post-processing applied to acquired data, which are examined backward starting from the Residual angle threshold 2.

The Residual point is found when the ratio of the gradients (the one in Residual angle threshold 2 being the reference) is greater than a set threshold (Slope change).

Given the multiplicative relation between the two gradients, if the reference gradient is too flat the residual point might be not properly detectable.

VARIANT A: The result is expected to be OK before the Residual angle threshold 1.

VARIANT B: The result is expected to be OK within Residual angle threshold 1 and Residual angle threshold 2.

How the gradient change strategy works?

We have defined the Slope change coefficient as the ratio of the gradients:  $\text{Slope Change} = m_{\text{result}}/m_{\text{ref}}$ .

Setting Slope change=1, we can get a result nearer to the reference (Residual angle threshold 2).

By increasing the value of the slope change, the algorithm will get a result farther from the reference (Residual angle threshold 2), where the ratio between the gradient of the result point and the gradient of the reference is higher (> Slope change).

In case of curves with different Breakaway and Residual points, if the algorithm doesn't find between Residual angle threshold and the local minimum a slope ratio surpassing the slope change set, then the result is always taken at the local minimum.

## Pset parameters

### Torque parameters

Parameter	Description
Cycle Start	Torque value from which the tightening operation starts.  This value must be higher than the min. load value of the transducer; if it is not, when the Pset starts, a "Min load error" message is shown on the display.
Angle threshold	For strategies that include the angle measurement, this parameter specifies the torque value from which the measurement of the angle starts.
Min torque	Lower torque limit.
Target torque	Torque value set as tightening goal.  Valid only for the strategies "Production: Torque Time" and "Production: Torque & Angle".
Max torque	Higher torque limit.
Torque correction coefficient	For normal operations, this parameter is set to 1 (default value for Torque correction coefficient). If an extension is used, this coefficient allows to compensate the effect of the extension on the torque measurement.  For further information, refer to <i>How to calculate the Torque Correction Coefficient [Page 42]</i> .
Change screw at	If the torque reaches this limit, the message "Change screw" is shown on the display. This parameter must be set higher than the Max torque value.
Unit of measurement	Select the desired unit.
Drag Torque type (Min, Max and Average)	It is the torque value resulting from the measurements taken within a pre-established angle interval. Select Min, Max or Average to calculate the Drag torque value.  Valid only for the strategies "Production: Prevailing Torque – Automatic compensation" and "Quality: Drag torque".
Prevailing min torque	It is the Drag torque lower limit of the first stage of the strategy. Valid only for the strategy "Production: Prevailing Torque – Automatic compensation".
Prevailing max torque	It is the Drag torque upper limit of the first stage of the strategy. Valid only for the strategy "Production: Prevailing Torque – Automatic compensation".
Drag torque compensation	This option permits to add or subtract the Drag torque to the torque peak in the second stage of the strategy.  Valid only for the strategy "Production: Prevailing Torque – Automatic compensation".
Final min torque	It is the lower limit of the Final target torque during the second stage of the strategy.  Valid only for the strategy "Production: Prevailing Torque – Automatic compensation".
Final target torque	It is the torque result of the tightening, considering the Drag Torque value.  Valid only for the strategy "Production: Prevailing Torque – Automatic compensation".
Final max torque	It is the upper limit of the Final target torque during the second stage of the strategy.  Valid only for the strategy "Production: Prevailing Torque – Automatic compensation".

Parameter	Description
Linear slope coefficient	<p>This parameter characterizes the joint stiffness in the linear part of the curve, as torque/angle slope. The minimum value of the Linear slope coefficient is 0.1; it suits also very soft joints with a ration less than 0.1. The default value is 0.5.</p> <p>Valid only for the strategy “Quality: Yield Point”.</p> <p><b>i</b> If the unit of measurement used is different from Nm, the Linear slope coefficient is automatically converted according to the unit of measurement selected.</p>

If the Q-SHIELD is connected while programming, the following torque parameters are set by default as follows:

- Cycle start = Angle threshold = Minimum torque = Maximum torque = 1% transducer nominal torque.
- Change screw at = Transducer nominal torque.
- Target torque (if available in the selected control strategy) = Transducer nominal torque (in this case also the Max torque is set to this value).

**i** All the Torque parameters defined for a Pset must be higher than the minimum load and lower than the capacity of the Q-SHIELD; otherwise, a Min Load error or a Capacity Error will be shown on the display when the Pset starts. Furthermore, the set of parameters must be reliable. For example, when storing a Pset, if the Min Torque is greater than the Target Torque, an error message is shown.

### Angle parameters

Parameter	Description
Min angle	Lower angle limit.
Max angle	Higher angle limit.
Target angle	<p>It is the angle value at which the residual torque is measured.</p> <p>Valid only for the strategies “Production: Torque + Angle” and “Quality: Residual Torque/Angle”.</p>
Angle correction coefficient	<p>For normal operations, this parameter is set to 0 (default value for Angle correction coefficient). If an extension is used, this coefficient allows to compensate the error in the angle reading due to the bending of the extension.</p> <p>For further information, refer to <i>How to calculate Angle Correction Coefficients</i> [Page 43].</p>
Prevailing min angle	<p>It is the lower limit of the angle interval during which torque values have to be checked in the first stage of the strategy.</p> <p>Valid only for the strategy “Production: Prevailing Torque – Automatic compensation”.</p>
Prevailing max angle	<p>It is the upper limit of the angle interval, during which torque values have to be checked in the first stage of the strategy.</p> <p>Valid only for the strategy “Production: Prevailing Torque – Automatic compensation”.</p>
Final min angle	<p>Valid only for the strategy “Production: Prevailing Torque – Automatic compensation”; it is the lower limit of the angle interval, during which the final torque value has to be checked.</p>
Final max angle	<p>It is the upper limit of the angle interval, during which the final torque value has to be checked.</p> <p>Valid only for the strategy “Production: Prevailing Torque – Automatic compensation”.</p>
Start angle	<p>It is the lower limit of the angle interval within which the torque value has to be checked.</p> <p>Valid only for the strategy “Quality: Drag torque”.</p>
Stop angle	<p>It is the upper limit of the angle interval within which the torque value has to be checked.</p> <p>Valid only for the strategy “Quality: Drag torque”.</p>


## Vibration parameter

Parameter	Description
Vibration start (% / Nm / Deg)	<p>It is possible to set Vibration start as a value expressed in percentage, torque, or angle.</p> <p>Vibration start (% / Nm / Deg) parameter is available for the following control strategies: “Production: Torque Time”, “Production: Torque &amp; Angle”, “Production: Torque + Angle”, “Production: Prevailing Torque – Automatic compensation”, “Quality: Residual Torque/Angle”, and “Quality: Drag Torque”.</p> <p>Set Vibration start (% / Nm / Deg) parameter in one of the following conditions:</p> <ul style="list-style-type: none"> <li>• when creating a new Pset</li> <li>• when, for a pre-existing Pset, it is necessary to change the control strategy</li> </ul> <p><b>i</b> By default, Vibration start (%) parameter is equal to 95%. It can range from 1 to 100%.</p>

- In case of **Production: Torque Time** control strategy, set Vibration start (%) or Vibration start (Nm) parameter. The Q-SHIELD starts vibrating after getting the percentage or torque related to the “vibrating target torque”. If Vibration start (%) is selected, below is an example to calculate the “vibrating target torque”:  
If:  
Cycle start = 2 Nm Target torque = 12 Nm  
Vibration start = 50%  
Then:  
“Useful torque interval” = (Target torque – Cycle start) × Vibration start = (12 – 2) Nm × 50% = 5 Nm  
Finally:  
Vibrating target torque = “Useful torque interval” + Cycle start = (5 + 2) Nm = 7 Nm  
During the test, if the tightening is within the limits (Max Torque and Min Torque) the vibration is continuous. If the tightening is out of the limits (Max Torque and Min Torque), the vibration is alternate.  
At the end of the test, if the tightening is OK, the Q-SHIELD vibrates for three times at a specified interval (1 second). If the tightening is NOK, the Q-SHIELD vibrates at specified intervals continuously; stop the vibration with one of the following procedures:
  - do a new tightening;
  - press OK → the Q-SHIELD is ready for a new measurement;
  - press CL → the Q-SHIELD exits from the Pset.
- In case of **Production: Torque & Angle** control strategy, set Vibration start (%) or Vibration start (Nm). The Q-SHIELD starts vibrating after getting the percentage or torque related to the “vibrating target torque”. If Vibration start (%) is selected, below is an example to calculate the “vibrating target torque”:  
If:  
Cycle start = 2 Nm Target torque = 12 Nm  
Vibration start = 50%  
Then:  
“Useful torque interval” = (Target torque – Cycle start) × Vibration start = (12 – 2) Nm × 50% = 5 Nm  
Finally:  
Vibrating target torque = “Useful torque interval” + Cycle start = (5 + 2) Nm = 7 Nm  
During the test, if the tightening is within the limits (Max/Min Torque and Max/Min Angle) the vibration is continuous. If the tightening is out of the limits (Max/Min Torque and Max/Min Angle), the vibration is alternate.  
At the end of the test, if the tightening is OK, the Q-SHIELD vibrates for three times at a specified interval (1 second). If the tightening is NOK, the Q-SHIELD vibrates at specified intervals continuously; stop the vibration with one of the following procedures:
  - do a new tightening;
  - press OK → the Q-SHIELD is ready for a new measurement;
  - press CL → the Q-SHIELD exits from the Pset.
- In case of **Production: Torque + Angle** control strategy, set Vibration start (%) or Vibration start (Deg). The Q-SHIELD starts vibrating after getting the percentage or angle related to the “target angle”.  
During the test, if the tightening is within the limits (Max/Min Torque and Max/Min Angle) the vibration is continuous. If the tightening is out of the limits (Max/Min Torque and Max/Min Angle), the vibration is alternate.  
At the end of the test, if the tightening is OK, the Q-SHIELD vibrates for three times at a specified interval (1 second). If the tightening is NOK, the Q-SHIELD vibrates at specified intervals continuously; stop the vibration with one of the following procedures:

- do a new tightening;
  - press OK → the Q-SHIELD is ready for a new measurement;
  - press CL → the Q-SHIELD exits from the Pset.
- In case of **Production: Prevailing Torque – Automatic compensation** control strategy, set Vibration start (%) or Vibration start (Nm). The Q-SHIELD starts vibrating after getting the percentage or torque related to the “target torque”.  
During the test, if the tightening is within the limits the vibration is continuous. If the tightening is out of the limits, the vibration is alternate.  
At the end of the test, if the tightening is OK, the Q-SHIELD vibrates for three times at a specified interval (1 second). If the tightening is NOK, the Q-SHIELD vibrates at specified intervals continuously; stop the vibration with one of the following procedures:
    - do a new tightening;
    - press OK → the Q-SHIELD is ready for a new measurement;
    - press CL → the Q-SHIELD exits from the Pset.
  - In case of **Quality: Residual Torque/Angle** and **Quality: Drag Torque** control strategies, set Vibration start (%) or Vibration start (Deg). The Q-SHIELD starts vibrating after getting the percentage or angle related to the Target angle or Stop angle respectively.  
During the test, if the tightening is within the limits (Max Torque and Min Torque) the vibration is continuous. If the tightening is out of the limits (Max Torque and Min Torque), the vibration is alternate.  
At the end of the test, if the tightening is OK, the Q-SHIELD vibrates for three times at a specified interval (1 second). If the tightening is NOK, the Q-SHIELD vibrates at specified intervals continuously; stop the vibration with one of the following procedures:
    - do a new tightening;
    - press OK → the Q-SHIELD is ready for a new measurement;
    - press CL → the Q-SHIELD exits from the Pset.
  - In case of **Quality: Residual Torque/Angle Automatic**, **Quality: Residual Peak/Torque** and **Quality: Yield Point** control strategies, the Q-SHIELD starts vibrating after getting the half of the torque limits:  $(\text{Max Torque} + \text{Min Torque}) / 2$ .  
During the test, if the tightening is over the Max Torque, the vibration is alternate.  
At the end of the test, if the tightening is OK, the Q-SHIELD vibrates for three times at a specified interval (1 second). If the tightening is NOK, the Q-SHIELD vibrates at specified intervals continuously; stop the vibration with one of the following procedures:
    - do a new tightening;
    - press OK → the Q-SHIELD is ready for a new measurement;
    - press CL → the Q-SHIELD exits from the Pset.
  - In case of **Quality: Residual Loose and Tighten** control strategy, the Q-SHIELD vibrates for 2 seconds when the loosening phase is completed, and at the end of the test when the Zero position is reached.  
During the test, if the tightening is over the Max Torque, the vibration is alternate.  
At the end of the test, if the tightening is OK, the Q-SHIELD vibrates for three times at a specified interval (1 second). If the tightening is NOK, the Q-SHIELD vibrates at specified intervals continuously; stop the vibration with one of the following procedures:
    - do a new tightening;
    - press OK → the Q-SHIELD is ready for a new measurement;
    - press CL → the Q-SHIELD exits from the Pset.

## Time parameters

Paramter	Description
End cycle time	<p>This parameter is applied when the torque goes below the cycle start after the target torque value is reached; the default value is 0.1 second.</p> <p>Minimum value: 0.1 seconds</p> <p>Maximum value: 5 seconds</p> <p> This parameter is not used for residual torque strategies.</p>

Paramter	Description
Abort cycle time	This parameter is applied when the torque goes down the cycle start but has not reached the target torque value yet. This allows the operator to release the torque for a while and recharge during the tightening operation; the default value is 5 seconds. Minimum value: 0.1 seconds Maximum value: 30 seconds

The Q-SHIELD ends the tightening operation if the torque drops below the Cycle Start value for a longer time than the timer.




Illustration 18: Torque vs. Time

A	Target torque	B	Cycle start
C	Abort cycle time	D	End cycle time

Before the torque reaches the Target Torque, the Abort Cycle Time is applied.

After the torque reaches the Target Torque, the End Cycle Time is applied.

The test ends when the torque remains below the Cycle Start value for more time than the timeout.


- ① For Residual torque strategies, the Abort Cycle Time is the only timeout available in the test strategy; for Residual Torque/Angle and Residual Torque/Angle Automatic, when the residual torque is detected the test ends even if the timeout has not expired.

### Batch parameters

Name	Description
Batch count	Select the check box to run the Pset more than one time.
Batch size	If Batch count is enabled, it specifies how many times the Pset must be executed. Maximum value: 99  ① If the Batch count is disabled, the Batch status in the tightening results is always OK. By enabling the Batch count and setting the Batch size to 1, the Batch result is OK only if the Pset result is OK. If the Batch size is greater than 1, the Batch result is OK only if all the Pset results are OK.

### Options parameters


Name	Description
Direction	Select the tightening direction of the test between clockwise (CW) and counterclockwise (CCW).

Name	Description
Measure Peak at	<p>Select between Torque and Angle.</p>  <p>A: Torque; B: Torque at torque peak; C: Torque at angle peak; D: Angle</p> <p><b>i</b> The torque result of a tightening changes according to the tightening strategy.</p>
Check RE-HIT	<p>If the operator tightens a screw that is already tightened, the torque increases with just a little rotation (or without any rotation) of the screw. This function monitors this event and shows an error message on the display.</p> <p>Select the check box to enable this function, and specify the Check RE-HIT value, that is typically set to few degrees.</p> <p>If the torque reaches the Min. Torque value within this angle, the error message “RE-HIT” is shown on the Q-SHIELD display.</p> <p><b>i</b> The Check RE-HIT option is available only for Production control strategies.</p>

### Correction Coefficients for extensions

When the joint design or space limitations preclude the use of standard sockets / tools, it may be necessary to use special extension spanners to fit the application. In these cases, the Q-SHIELD measurements must be adequately compensated since the factory calibration is made for the standard arm, and the extension arm (E) increases the torque measured. The angle measured is also affected by the extensions, due to its specific torsion when torque is applied.

### How to calculate the Torque Correction Coefficient



D	Torque value displayed	T	Applied torque
L	Standard arm (from the center of the handle to the center of the end fitting tool)	L+E	Total arm
E	Extension arm		

From the relation between the displayed and applied torque  $T = \frac{D \times (L+E)}{L}$ , the torque correction coefficient is given by the following formula:

$$\text{Torque correction coefficient} = \frac{L+E}{L}$$

## How to calculate Angle Correction Coefficients

When an extension is used, the angle correction coefficient allows linear compensation of extension torsion due to the torque applied. The value is expressed in degrees at the device capacity.

To calculate the proper angle correction coefficient, the torque coefficient of the extension must be already calculated (refer to *How to calculate the Torque Correction Coefficient [Page 42]*) and specified in the Pset used for calculating the angle correction coefficient.

1. Create a Pset with the following parameters:
  - Control strategy: Torque & Angle
  - Torque correction coefficient: 1
  - Target torque: 80% of the device capacity
  - Cycle start and Angle threshold: 10% of the Q-SHIELD capacity
  - Minimum angle: 0
  - Target angle: 15
  - Maximum angle: 30
  - Check RE-HIT: Disabled
2. Start the Pset.
3. Apply the target torque specified in the Pset, operating the device on a vise (or on static transducer).
  - ⓘ Since for this test the Torque Correction Coefficient is set to 1, the torque applied to the vise is higher than the torque shown on the display. The vise must support at least the maximum torque of the Pset multiplied by the Torque Correction Coefficient calculated above.
4. The angle displayed is the bending of the extension applied to the torque shown on the display. Therefore, the Angle Correction Coefficient is equal to the following formula:

**Angle Correction Coefficient = Q-SHIELD Capacity / (Torque measured - Angle threshold) x Angle measured**

- ⓘ The Q-SHIELD Capacity is the **Max torque** value shown in DeltaQC in the information of the **Transducers > Connected transducer**.
- ⓘ After storing the Angle Correction Coefficient, it is NOT possible to use the Demo mode to verify the correct operation of the angle coefficient, since the Demo mode does not consider the correction coefficients. Therefore, for a verification test, a Pset must be used.

## Correction formulas

During the tightening, the torque and angle measured by the transducers are corrected to obtain the real torque and angle values that are displayed on the Q-SHIELD and used in the tightening curves and results. The correction formulas are as follows:

**Torque displayed = Torque measured x Torque Correction Coefficient**

**Angle displayed = Angle measured - Angle Correction Coefficient x [(Torque displayed - Angle threshold) / (Q-SHIELD Capacity - Torque Correction Coefficient)]**

- ⓘ The Q-SHIELD Capacity is the **Max torque** value shown in DeltaQC in the information of the **Transducers > Connected transducer**.

Founded in 1914 and headquartered in France, Desoutter Industrial Tools is a global leader in electric and pneumatic assembly tools serving a wide range of assembly and manufacturing operations, including Aerospace, Automotive, Light and Heavy Vehicles, Off-Road, General Industry.

Desoutter offers a comprehensive range of Solutions -tools, service and projects- to meet the specific demands of local and global customers in over 170 countries.

The company designs, develops and delivers innovative quality industrial tool solutions, including Air and Electric Screwdrivers, Advanced Assembly Tools, Advanced Drilling Units, Air Motors and Torque Measurement Systems.

**Find more on [www.desouttertools.com](http://www.desouttertools.com)**

**More Than Productivity**