


## RC6070 - Decommissioning Instructions



- |      |               |
|------|---------------|
| (AL) | Aluminium     |
| (IR) | Iron          |
| (Br) | Brass         |
| (TP) | Thermoplastic |
| (Ru) | Rubber        |
| (St) | Steel         |