




REVERSE HANDLE

Part number 615396878 0



Original instructions.

© COPYRIGHT 2014, DESOUTTER HP2 7SJ UK


All rights reserved. Any unauthorized use or copying of the contents or part thereof is prohibited. This applies in particular to trademarks, model denominations, part numbers and drawings. Use only authorized parts. Any damage or malfunction caused by the use of unauthorised parts is not covered by Warranty or Product Liability.

Software and documentation available at:

<http://resource-center.desouttertools.com>

No login/password required.

COMPLETE TOOL



Item	Description	Part number	Qty
1	Reverse button	6159155770	1
2	M8 male connector cable	6159380820	1